

Use, warnings and maintenance
instruction manual

“RECHARGEABLE UNDER HOOD LED LAMP WITH PORTABLE
REMOVABLE LED LAMP”



ENGLISH

WARNINGS AND SAFETY INSTRUCTIONS

Before using the lamp, carefully read the warnings and instructions contained in this manual. This warning and instruction manual is an integral part of the product and must be kept by the user for any future consultation. It contains important information on the safe use of the product.

Use destination. This lamp and its accessories must be used only for the purpose for which they were designed. Any use other than that indicated could cause damage to people, animals or things and is considered an improper and unreasonable act. The manufacturer cannot be held responsible for any damage caused by improper, erroneous or unreasonable use such as, for example, failure to comply with the instructions and warnings provided, the use of non-original accessories, modifications or unauthorized interventions on the product.

Attention: failure to comply with these safety instructions could cause serious damage to people, the environment and the lamp itself.

This device is not a toy. Keep out of reach of children.

The packaging material (cardboard box, plastic sheets, etc.) must not be used by children for play.

Do not immerse or subject the device to jets of water. Do not use the lamp in a potentially explosive atmosphere, such as near combustibles, flammable gas or dust. Respect and abide by the limitations and provisions of the law.

Do not throw into fire or expose to flames. Danger of explosion.

Do not look or point the light directly into the eyes.

Use the charger indoors and away from humidity.

Falling events can irreparably damage the lamp and its accessories and are not covered by warranty. In this case, in order to avoid any risk, do not use the lamp and its accessories, but contact an authorized service center.

Do not try to open the lamp or the accessories supplied; there are no replaceable parts. Interventions by unqualified personnel are potentially dangerous and invalidate the guarantee.

Use only the accessories supplied with the lamp. The use of non-original accessories will invalidate the warranty and could be a source of danger with the risk of fire, explosion, liquid leakage or other hazards. For the availability of the original accessories, contact an authorized dealer.

For use and charging, comply with the temperature conditions listed in the TECHNICAL FEATURES chapter.

Avoid exposure to temperatures that are too high which can reduce the life of electronic circuits, damage batteries and deform or melt plastic parts.

Also avoid exposure to too low temperatures which can reduce battery life or make plastic components fragile.

Avoid handling or disconnecting the charging device by pulling it by the cable.

PRECAUTIONS FOR USE

The information in this section will help the user to comply with the warranty requirements and keep the lamp efficient.

- Turn off the lamp when not in use.
- Never leave the lamp with a completely discharged battery.
- Fully recharge the battery if the lamp is not to be used for a long time (one month or more).
- Before first use, fully charge the lamp.
- Before cleaning the lamp, always unplug the charging cable.
- Clean preferably with a dry or slightly damp cloth. Do not use solvents, alcohol, corrosive chemicals or aggressive detergents.
- To use, charge and store the lamp, comply with the temperature conditions listed in the TECHNICAL FEATURES chapter. Do not leave the lamp for a long time in too hot or cold environments.

TECHNICAL FEATURES

Size(mm):	1300 (2060) x 77 x 135
Weight (gr):	1720
LED type:	SMD
Brightness of under hood lamp :	1200 lm
Brightness of portable removable lamp (min – max)	60 lm – 200 lm
Functions:	30%; 100%; OFF

Technical features of under hood lamp's battery:	7.4V 5200mAh
Technical features of removable lamp's battery	7.4V 750mAh
Batterycharge's technical features:	12V 2.5A
Recharge time:	4 – 5 h
Run time of under hood lamp's battery:	3 h
Run time of removable lamp's battery	2.5 h

Working and storage temperature:	
Storage:	-20°C to +50°C (1 year)
Charge:	-10°C to +40°C
Working:	-10°C to +40°C


INSTRUCTIONS FOR USE

UNDER HOOD LED LAMP

To turn on the lamp use the Power button on the front. Check the battery charge status using the 4 blue LED indicator placed next to the power button (the lamp is fully charged when the 4 LEDs are all on). If necessary, recharge using the appropriate wall charger supplied. The side hooks can be extended until the desired length is reached (maximum 2060 mm). Once the lamp is attached, it can be rotated to the ideal position without having to detach it.

PORTABLE REMOVABLE LED LAMP

This lamp is equipped with a portable lamp that can be easily released if necessary. To turn it on, use the power button on the back where there are also two magnets that allow you to hang the lamp on metal surfaces: The first time you press the power button, the lamp turns on at maximum brightness (200 lm); the second pressure switches to minimum intensity (60 lm); at the third press the lamp turns off. To recharge it, hang it up on the lamp and use the supplied wall charger.



DISPOSAL INFORMATION

This product falls within the scope of the Directive 2012/19/EU (RAEE).

The symbol of a crossed-out bin on the product and/or on the packaging, means that this product is not to be disposed off with your household waste, it should be handed over to an authorized collection site for disposal and recycling. This operation has to be carried out by the consumer. The correct disposal of the product will contribute to avoid the possible negative effects on the environment and encourages the usage of renewable resources.



EU DECLARATION OF CONFORMITY

This product is in compliance with the following European Directives:
2014/30/EU (EMC): EN 55015:2013+A11:2015; EN 61000-3-2:2014; EN 61547:2009; EN 61000-3-3: 2013
2015/863/EU (RoHS): EN 62321-2:2013; EN 62321-1:2013; EN 62321-3-1:2013; EN 62321-4:2013; EN 62321-5: 2013; EN 62321-7-2: 2017; EN 62321-6; 2015
2014/35/EU (LVD): EN 62368-1

WARRANTY

This lamp is guaranteed 24 months from the date of the purchase; in the case of purchase. The warranty is not extended for periods of downtime caused by repairs.

Warranty means the repair or replacement free of charge, including work, components found defective in manufacture or materials.

The warranty does not apply in all cases where the damage is caused by carelessness, use or maintenance not in accordance with the instructions of this manual; particularly in case of product tampering or negligence of the customer. The warranty does not apply to failures caused by inductive/electrostatic dischargers caused by lightning or other external events to the product.

The warranty does not extend to parts subject to wear due to use, connecting cables and connectors that are free from defects in manufacture are excluded from the warranty.